


M/TACTICAL®

THE PLACE FOR FLASHLIGHT FREAKS

COB HEADLAMP User Guide

Features:



Specifications: Size: 31 x 3.2 x 4cm (LxWxH); Weight: 99g

Output & Runtime:

| | White High | White Low | Yellow High | Yellow Low | Red High |
|--|---------------|--------------|---------------|---------------|---------------|
| | 185 LUMENS | 90 LUMENS | 185 LUMENS | 90 LUMENS | 185 LUMENS |
| | 3h | 4h | 3h | 4h | 3h |
| | Red Strobe | LED High | LED Low | W+Y High | W+Y Strobe |
| | 185 LUMENS | 70 LUMENS | 30 LUMENS | 370 LUMENS | 370 LUMENS |
| | 4h | 3h | 5h | 1.5h | 3h |

Charging:

- To charge, plug USB-C end of cable into COB Headlamp and USB-A end into power source. After 20 secs, red light will indicate battery is charging. When red light turns green (approx. 4 hrs.), your COB Headlamp is fully charged and ready to go.



Operation:

- Click the ON/OFF switch to turn on. Once on, click ON/OFF again to change modes. Modes will cycle in this order: COB cool white high, COB cool white low, COB warm white high, COB warm white low, COB red high, COB red strobe, side LED high, side LED low, then off.
- For instant on in the brightest mode from off or any mode, click and hold the ON/OFF switch for 2 secs, which will activate both the cool white and warm white COBs on high. Once in full on, a single click of the ON/OFF button turns to cool white/warm white strobe. One more single click will turn the headlamp off.
- When the light is on, a single click of the sensor switch enters sensor mode: a wave of your hand in front of the sensor light to turn on and off; click again the sensor switch to turn off sensor mode function.
- Power indicator will be green when battery is 20% charged or higher and red when battery is below 20% charge.

Thank you for purchasing a quality M/TACTICAL product! v.1.2